


ASSEMBLY INSTRUCTIONS



Erika Three-Tier Chandelier

Item # TOB5206

WE RECOMMEND INSTALLATION OF THIS LIGHTING FIXTURE BE DONE BY A LICENSED ELECTRICIAN.

WARNING * SWITCH OFF THE MAIN ELECTRICAL SUPPLY FROM THE MAIN FUSE BOX/CIRCUIT BREAKER BEFORE INSTALLATION.**

INSPECT ITEM CAREFULLY BEFORE ATTEMPTING TO INSTALL. IF THERE IS ANY DAMAGE OR OBVIOUS DEFECT, DO NOT INSTALL.

ITEM MAY NOT BE RETURNED ONCE IT HAS BEEN INSTALLED.

1. Attach chain (F) to top loop (G) by opening/closing end link of chain.
2. Attach chain (F) with fixture to chain mounting loop (E) at desired height.
3. Remove mounting plate (A) from canopy (C) by removing base screws (D).
4. Gently pull the wires from ceiling outlet box and allow the wires to hang. Thread the wires through the center hole of mounting plate (A).
5. Affix mounting plate (A) onto ceiling outlet box and secure with mounting screws (B).
6. Attach the ground wire (bare wire) from the fixture to the ground junction box wire (usually green or copper wire). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed.
7. Connect the neutral wire from the fixture (ridges molded wire) to the neutral wire from the junction box (usually white). Fasten together with a plastic wire connector and wrap the connection with electrical tape. Be sure no wire strands are exposed.
8. Connect the hot wire from the fixture (smooth wire) to the hot wire (usually black) from the junction box. Fasten each together with a plastic wire connector and wrap the connection with electrical tape. Be sure that no wire strands are exposed. **DO NOT REVERSE THE HOT AND NEUTRAL CONNECTIONS OTHERWISE SAFETY WILL BE COMPROMISED.**
9. Attach canopy (C) to mounting plate (A) by aligning the side holes and secure with base screws (D).
10. Insert light bulbs into sockets. Restore power and test fixture.



UNPACKING NOTICE

Erika Three-Tier Chandelier

Item # TOB5206

1. Due to the nature of this packaging, some arms may need slight adjustment after hanging.
2. Hold lower portion of arm (A) with one hand and pull up/down on the bobèche (B) with other hand to correct any inconsistencies as needed.

